



Nocte Lux

Written By: Mahesh Venkitachalam



TOOLS:

- [Soldering/desoldering tools \(1\)](#)




PARTS:

- [555 timer SO-8 package \(1\)](#)
- [1206 SMD resistor 1K \(1\)](#)
- [1206 SMD resistor 10K \(1\)](#)
- [1206 SMD resistor 1M \(1\)](#)
- [1206 SMD resistor 470K \(1\)](#)
- [1206 SMD capacitor 0.01uF \(1\)](#)
- [1206 or B SMD 100 uF capacitor \(1\)](#)
- [MOSFET MMBF170 SMD \(2\)](#)
- [Tilt switch \(1\)](#)

SUMMARY

For this project, I wanted to try and make a simple night lamp – something that you can put under your cot and use it simply by picking it up. Useful in case you get up in the middle of the night and need a quick light. So I used a tilt switch and a 555 IC to design the circuit.

Step 1 — Nocte Lux




- Download schematic and PCB design (EAGLE files) from [here](#).
- The tilt sensor I used is **closed** when upright. If you get one which is **open** when upright, no worries. Just mount it upside down, and you can use the same circuit. The important thing is that the switch should be **closed** in the default position of the lamp. You can read about tilt switches [here](#).
- You can read about the project in detail [here](#).

Step 2



- You can make the PCB at home using the toner transfer process described [here](#).
- In this case, I greatly accelerated the process by sponging the PCB directly using ferric chloride. You can read about this technique [here](#).

Step 3



- This project uses surface mount (SMD) components. If you haven't done an SMD circuit before, don't be intimidated by it. You don't need any fancy equipment to make an SMD circuit at home.
- Here is [a wonderful cartoon guide](#) to SMD soldering.
- As you can see from the photo, using SMD results in a very compact board compared to regular (through-hole) components.

Step 4



- I used a cheap translucent plastic container to house the circuit.
- The LED strip can be hot glued onto the inside of the container in the shape of a helix.
- The 9V battery holder is glued to the bottom of the container, and the PCB glued on to the side of it. Ensure that the title sensor is oriented so that the switch is **closed** in the default position.
- Have fun making your night lamp!

This document was last generated on 2013-01-27 03:20:19 AM.